Sprayable

A flawless finish made easy



Enrol in a Dulux Academy spray course

"You learn everything on the course including the masking and preparation. There was lots of time to also have a go yourself, with the trainer on hand for tips."

Paul, PS Painting & Decorating

Dulux ACADEMY

Spray Introduction
1-day - £150+VAT

Spray Advanced - HVLP
1-day - £175+VAT

Spray Advanced - Airless
1-day - £175+VAT

Kitchen & Furniture Refurbishment
1-day - £175+VAT

Click here to find out more about content, location and date availability for Spray courses.

Dulux ACADEMY LIVE

If you can't get to us, check out **Dulux Academy Live** workshops which are free to dial into from anywhere with an internet connection.

For more information on **Dulux Academy courses, click here**

Dulux Trade **recommended products**

	Thinning	Bare/porous substrates	Low Pressure tip	Fine Finish Tip	Regular Tip	HVLP
Please note that the below recommendations are intended as a guideline only and some adjustments may need to be made to accommodate equipment type & age, substrate type and individual site & atmospheric conditions.						
Dulux Trade Diamond Matt PBW	No thinning required but can be thinned up to 10% (1 part water to 10 parts paint)	•	✓ For best results, use a 515 or 517 low pressure tip @ 1300 - 1700 psi. (89 – 117 bar).	•	✓ Alternatively, use a 517 tip @ 2000 – 2400 psi (138 - 165 bar)	•
Dulux Trade Diamond Eggshell PBW	No thinning required	•	✓ For best results, use a 517 Low Pressure tip @ 1300 -1700 psi (89 – 117 bar).	•	✓ Alternatively, use a 517 tip @ 2000 – 2400 psi (138 - 165 bar)	•
Dulux Trade Vinyl Matt PBW	✓ For normal use thin up to 10% (1 part water to 10 parts paint)	✓ For bare/porous substrates thin up to 20%, 517 Low Pressure tip @ 1000 – 1400 psi (68 – 96 bar)	✓ For best results, use a 517 Low Pressure tip @ 1000 - 1400 psi (68 – 96 bar).	•	✓ Alternatively, use a 517 tip @ 2000 – 2300 psi (138 - 158 bar)	•
Dulux Trade Supermatt PBW	✓ For normal use thin up to 10% (1 part water to 10 parts paint)	✓ For bare/porous substrates thin up to 33% (1 part water to 3 parts paint) For best results use a 517 Low Pressure tip @ 1000 - 1400 psi (68 – 96 bar) Alternatively, use a 517 tip @ 2300 – 2700 psi (158 - 186 bar)	✓ For best results, use a 517 Low Pressure tip @ 1500 - 1900 psi. (100 – 130 bar)	•	✓ Alternatively, use a 517 tip @ 2300 – 2700 psi (158 - 186 bar)	•
The below trim paints are susceptible to sagging when applied above 75 µ. For this reason, HVLP is the safer option as this method is naturally slower and more gentle and therefore easier to control. The use of airless spray should only be considered by a competent and experienced sprayer for these products.						
Dulux Trade Quick Dry Undercoat White	✓ HVLP: thin up to a maximum of 15% Airless: no thinning required	•	•	✓ HVLP: use a 1.8mm fluid set Airless: use a 208 or 308 fine finish tip @ 1100 - 1500 psi. (80 - 100 bar)	•	✓ Thin up to a maximum of 15% and use a 1.8mm Fluid Set Airless Spray
Dulux Trade Quick Dry Gloss PBW	✓ HVLP: thin up to a maximum of 15% Airless: no thinning required	•	•	✓ HVLP: use a 1.8mm fluid set Airless: use a 208 or 308 fine finish tip @ 1100 - 1500 psi. (80 - 100 bar)	•	✓ Thin up to a maximum of 15% and use a 1.8mm Fluid Set Airless Spray
Dulux Trade Quick Dry Satinwood PBW	✓ HVLP: thin up to a maximum of 20% Airless: can be thinned up to 5%	•	•	✓ HVLP: use a 1.8mm fluid set Airless: use a 208 or 308 fine finish tip @ 1100 - 1500 psi. (80 - 100 bar)	•	✓ Thin up to a maximum of 20% and use a 1.8mm Fluid Set Airless Spray
Dulux Trade Diamond Satinwood PBW	✓ HVLP: thin up to a maximum of 20% Airless: no thinning required	•	•	✓ HVLP: use a 1.8mm fluid set Airless: use a 208 or 308 fine finish tip @ 1100 - 1500 psi. (80 - 100 bar)	•	✓ Thin up to a maximum of 20% and use a 1.8mm Fluid Set Airless Spray

Click here for the full Dulux Trade product range

To view data sheet & documents, click here