



Painting Instructions for Magply

All joints, screw heads, nail holes etc should first be filled using Magply Ready Mixed Filler Adhesive, which is left for 24hrs and sanded down flat.

The recommended paint for Magply is Bedec Multi Surface www.bedec.co.uk which is available nationally through Brewers Decorating Suppliers www.brewers.co.uk.

First Coat

Magply is a high suction background so the first coat of multi surface is mixed with 25-30% water and allowed to dry.

Subsequent Coats

Bedec Multi surface should be applied neat there after until the desired finish is achieved.