

# Translation Tables.

## The new Naming Schöck Isokorb®.

### Schöck Isokorb® XT Typ K (Previous Type KXT)

New Name	Previous	
	Product, Model, Type	Load capacity Type
Isokorb® XT Typ K	M1-V1	KXT15-V6
Isokorb® XT Typ K	M1-V2	KXT15-V8
Isokorb® XT Typ K	M2-V1	KXT25-V6
Isokorb® XT Typ K	M2-V2	KXT25-V8
Isokorb® XT Typ K	M3-V1	KXT30-V6
Isokorb® XT Typ K	M3-V2	KXT30-V8
Isokorb® XT Typ K	M3-VV1	KXT30-VV
Isokorb® XT Typ K	M4-V1	KXT40-V6
Isokorb® XT Typ K	M4-V2	KXT40-V8
Isokorb® XT Typ K	M4-VV1	KXT40-VV
Isokorb® XT Typ K	M5-V1	KXT45-V6
Isokorb® XT Typ K	M5-V2	KXT45-V8
Isokorb® XT Typ K	M5-VV1	KXT45-VV
Isokorb® XT Typ K	M6-V1	KXT50-V6
Isokorb® XT Typ K	M6-V2	KXT50-V8
Isokorb® XT Typ K	M6-VV1	KXT50-VV
Isokorb® XT Typ K	M7-V1	KXT55-V8
Isokorb® XT Typ K	M7-V2	KXT55-V10
Isokorb® XT Typ K	M7-VV1	KXT55-VV
Isokorb® XT Typ K	M8-V1	KXT65-V8
Isokorb® XT Typ K	M8-V2	KXT65-V10
Isokorb® XT Typ K	M8-VV1	KXT65-VV
Isokorb® XT Typ K	M9-V1	KXT90-V8
Isokorb® XT Typ K	M9-V2	KXT90-V10
Isokorb® XT Typ K	M10-V1	KXT100-V8
Isokorb® XT Typ K	M10-V2	KXT100-V10

### Schöck Isokorb® XT Typ Q (Previous Type QXT und QXT+QXT)

New Name	Previous	
	Product, Model, Type	Load capacity Type
Isokorb® XT Typ Q	V1	QXT10
Isokorb® XT Typ Q	VV1	QXT10+QXT10
Isokorb® XT Typ Q	V2	QXT20
Isokorb® XT Typ Q	VV2	QXT20+QXT20
Isokorb® XT Typ Q	V3	QXT30
Isokorb® XT Typ Q	VV3	QXT30+QXT30
Isokorb® XT Typ Q	V4	QXT40
Isokorb® XT Typ Q	VV4	QXT40+QXT40
Isokorb® XT Typ Q	V5	QXT60
Isokorb® XT Typ Q	VV5	QXT60+QXT60
Isokorb® XT Typ Q	V6	QXT70
Isokorb® XT Typ Q	VV6	QXT70+QXT70
Isokorb® XT Typ Q	V7	QXT80
Isokorb® XT Typ Q	VV7	QXT80+QXT80
Isokorb® XT Typ Q	V8	QXT90
Isokorb® XT Typ Q	VV8	QXT90+QXT90

### Schöck Isokorb® XT Typ Q-P (Previous Type QPXT)

New Name	Previous	
	Product, Model, Type	Load capacity Type
Isokorb® XT Typ Q-P	V1	QPXT10
Isokorb® XT Typ Q-P	VV1	QPXT10+QPXT10
Isokorb® XT Typ Q-P	V2	QPXT20
Isokorb® XT Typ Q-P	VV2	QPXT20+QPXT20
Isokorb® XT Typ Q-P	V3	QPXT30
Isokorb® XT Typ Q-P	VV3	QPXT30+QPXT30
Isokorb® XT Typ Q-P	V4	QPXT40
Isokorb® XT Typ Q-P	VV4	QPXT40+QPXT40
Isokorb® XT Typ Q-P	V5	QPXT50
Isokorb® XT Typ Q-P	VV5	QPXT50+QPXT50
Isokorb® XT Typ Q-P	V6	QPXT60
Isokorb® XT Typ Q-P	VV6	QPXT60+QPXT60
Isokorb® XT Typ Q-P	V7	QPXT70
Isokorb® XT Typ Q-P	VV7	QPXT70+QPXT70
Isokorb® XT Typ Q-P	V8	QPXT75
Isokorb® XT Typ Q-P	VV8	QPXT75+QPXT75
Isokorb® XT Typ Q-P	V9	QPXT100
Isokorb® XT Typ Q-P	VV9	QPXT100+QPXT100

### Schöck Isokorb® T Typ K (Previous Type K)

New Name	Previous	
	Product, Model, Type	Load capacity Type
Isokorb® T Typ K	M1-V1	K10-V6
Isokorb® T Typ K	M1-V2	K10-V8
Isokorb® T Typ K	M2-V1	K20-V6
Isokorb® T Typ K	M2-V2	K20-V8
Isokorb® T Typ K	M3-V1	K25-V6
Isokorb® T Typ K	M3-V2	K25-V8
Isokorb® T Typ K	M3-V3	K25-V10
Isokorb® T Typ K	M4-V1	K35-V6
Isokorb® T Typ K	M4-V2	K35-V8
Isokorb® T Typ K	M4-V3	K35-V10
Isokorb® T Typ K	M4-VV1	K35-VV
Isokorb® T Typ K	M5-V1	K45-V6
Isokorb® T Typ K	M5-V2	K45-V8
Isokorb® T Typ K	M5-V3	K45-V10
Isokorb® T Typ K	M5-VV1	K45-VV
Isokorb® T Typ K	M6-V1	K47-V6
Isokorb® T Typ K	M6-V2	K47-V8
Isokorb® T Typ K	M6-V3	K47-V10
Isokorb® T Typ K	M6-VV1	K47-VV
Isokorb® T Typ K	M7-V1	K55-V8
Isokorb® T Typ K	M7-V2	K55-V10
Isokorb® T Typ K	M7-VV1	K55-VV
Isokorb® T Typ K	M8-V1	K65-V8
Isokorb® T Typ K	M8-V2	K65-V10
Isokorb® T Typ K	M8-VV1	K65-VV
Isokorb® T Typ K	M9-V1	K75-V8
Isokorb® T Typ K	M9-V2	K75-V10
Isokorb® T Typ K	M9-VV1	K75-VV
Isokorb® T Typ K	M10-V1	K90-V8
Isokorb® T Typ K	M10-V2	K90-V10
Isokorb® T Typ K	M10-VV1	K90-VV
Isokorb® T Typ K	M11-V1	K100-V10
Isokorb® T Typ K	M11-VV1	K100-VV

### Schöck Isokorb® T Typ Q (Previous Type Q und Q+Q)

New Name	Previous	
	Product, Model, Type	Load capacity Type
Isokorb® T Typ Q	V1	Q10
Isokorb® T Typ Q	VV1	Q10+Q10
Isokorb® T Typ Q	V2	Q20
Isokorb® T Typ Q	VV2	Q20+Q20
Isokorb® T Typ Q	V3	Q30
Isokorb® T Typ Q	VV3	Q30+Q30
Isokorb® T Typ Q	V4	Q40
Isokorb® T Typ Q	VV4	Q40+Q40
Isokorb® T Typ Q	V5	Q50
Isokorb® T Typ Q	VV5	Q50+Q50
Isokorb® T Typ Q	V6	Q70
Isokorb® T Typ Q	VV6	Q70+Q70
Isokorb® T Typ Q	V7	Q80
Isokorb® T Typ Q	VV7	Q80+Q80
Isokorb® T Typ Q	V8	Q90
Isokorb® T Typ Q	VV8	Q90+Q90
Isokorb® T Typ Q	V9	Q100
Isokorb® T Typ Q	VV9	Q100+Q100
Isokorb® T Typ Q	V10	Q110
Isokorb® T Typ Q	VV10	Q110+Q110

### Schöck Isokorb® T Typ Q-P (Previous Type QP und QP+QP)

New Name	Previous	
	Product, Model, Type	Load capacity Type
Isokorb® T Typ Q-P	V1	QP10
Isokorb® T Typ Q-P	VV1	QP10+QP10
Isokorb® T Typ Q-P	V2	QP20
Isokorb® T Typ Q-P	VV2	QP20+QP20
Isokorb® T Typ Q-P	V3	QP30
Isokorb® T Typ Q-P	VV3	QP30+QP30
Isokorb® T Typ Q-P	V4	QP40
Isokorb® T Typ Q-P	VV4	QP40+QP40
Isokorb® T Typ Q-P	V5	QP50
Isokorb® T Typ Q-P	VV5	QP50+QP50
Isokorb® T Typ Q-P	V6	QP60
Isokorb® T Typ Q-P	VV6	QP60+QP60
Isokorb® T Typ Q-P	V7	QP70
Isokorb® T Typ Q-P	VV7	QP70+QP70
Isokorb® T Typ Q-P	V8	QP80
Isokorb® T Typ Q-P	VV8	QP80+QP80
Isokorb® T Typ Q-P	V9	QP90
Isokorb® T Typ Q-P	VV9	QP90+QP90