

### **SAFETY AND MAINTENANCE**

## **COVER SKATE** ACCESS COVER LIFTING



# Make light work of lifting heavy floor access covers with the Howe Green COVER SKATE

The Howe Green COVER SKATE is the ingenious way to lift heavy floor access covers. Simple, convenient and extremely portable you can carry the Cover Skate in a bag and lift even the heaviest of covers on your own – safely, easily and quickly.

#### >> FEATURES

- Easy to carry and store
- Very durable and corrosion resistant
- Simple and quick to use
- 300 kg lift from each COVER SKATE
- Lifting keys to suit other manufacturers covers available to order
- Two skates per cover at opposite corners allow wheeled movement of the cover away from the opening



SAFE ACCESS ALL AREAS


Using the COVER SKATE means you need less people to do the job and don't have to worry about the health and safety issues that come with using bigger pieces of equipment. Suitable for use in all types of locations from airports, factories and hospitals to hotels, offices and schools the COVER SKATE gives you access to concealed services quickly, safely and cost effectively.

#### >> INSTRUCTIONS FOR USE

- Remove cover securing bolts.
- 2 Place a COVER SKATE over a cover lifting point with the wheels outside the outer frame.
- 3 Remove the COVER SKATE bolt from the storage position and screw into the cover lifting point until fully home and hand tight, ensuring that the base of the COVER SKATE is flush with the cover.
- **4** Take the second COVER SKATE and repeat the above on the diagonally opposite lifting point.
- 5 Turn the jacking handle clockwise on one of the COVER SKATEs until the cover edge has lifted by approximately 1 cm.
- **6** Now using the second COVER SKATE lift the other side of the cover by approximately 1 cm.
- 7 The cover should now be raised as evenly as possible using the two COVER SKATEs until it is clear of the outer frame.
- 8 Carefully wheel the cover to one side of the opening, making sure that the hole is cordoned off to prevent falls.
- 9 To replace the cover ensure that the cover and the frame are clean and then follow the above in reverse order.







#### **Sales Enquiries**

+44(0)1920 463 230 info@howegreen.co.uk www.howegreen.com Innovation drive, Wolverhampton, West Midlands, WV9 5GA, UK

