





Before starting any Eurobrick Systems installation, please read the instructions carefully. V-Clad must be installed in accordance with these instructions.

If any questions do arise, contact our Technical Support Department by calling 0117 971 7117 or emailing [info@eurobrick.co.uk](mailto:info@eurobrick.co.uk).

## Product data

**Panel:** Formed by profile cutting expanded polystyrene insulation (EPS) to produce a pattern of horizontal ribs. Panel size is 1221mm high x 1200mm wide x 20mm thick (up to 100mm thick can be supplied for large orders).

**Bricks:** All brick slips supplied by Eurobrick are kiln fired clay.

**Britannia range brick slips are nominally sized:**

**Slips** 215mm x 65mm x 14-15mm

**Corners** 215mm x 65mm x 102mm x 65mm x 14-15mm

**Classic range brick slips are nominally sized:**

**Slips** 215mm x 65mm x 20-25mm

**Corners** 215mm x 65mm x 102mm x 65mm x 20-25mm

**Fasteners:** Nylon plastic washer, 45mm diameter, used in conjunction with a wood or stainless steel screw and specialist masonry fixings. Fasteners to be installed 15 per square metre (minimum). Please specify substrate type (timber, metal or masonry) when ordering.

**Adhesive:** One part high grab MS polymer adhesive moisture curing, non-hardening which remains gunable even at temperatures as low as 2°C, for normal applications. Supplied in 600ml sachets covering approximately 0.8m<sup>2</sup> (48 brick slips).

**Mortar:** Eurobrick's Europoint mortar is specially formulated to enhance ease of application, adhesion properties and flexibility. Just add clean water and mix. Supplied in 25kg bags; 1 bag covers between 2.5-5 square metres subject to brick thickness and efficiency of use.

**Installed system weight:** System weight approx 36–40kg/square metre, subject to specification.

## Applications

Eurobrick Systems can be applied over any structurally sound flat surface:

- Sheathing on metal or timber framing – Figure 1
- Masonry – Figure 2

Application over other substrates is possible, however over asbestos, vinyl/UPVC cladding or any substrate unable to provide adequate fixing strength is not recommended.

### PLEASE NOTE

Substrate surfaces must be dry, flat and stable.




Figure 1




Figure 2



## Tools

To ensure ease of installation we recommend you have the following tools:

- 120mm diameter powered disk cutter or wet saw
- Adhesive applicator gun\*
- Pointing bag with metal tip\*
- Joint pointing tool\*
- Powered screwdriver
- 2m level
- Chalk line
- Utility knife
- Measuring tape
- Marker pen

\* See Accessories list.

### PLEASE NOTE

You will need a masonry saw with a diamond edged blade if any angular or horizontal cutting of brick is required. Suitable PPE protection must be worn.

## Limitations

### 1. Application temperature range

Eurobrick Systems should not be applied to surfaces that will exceed 140°F (60°C).

### 2. Supporting frame member spacing

Where V-Clad panels are to be fixed to battens or studs (creating a cavity), these **MUST** be set out to satisfy system fixing requirements.

There must be 4 vertical fixing members behind each 1.2m wide panel. See Figure 3.

### 3. Fire Rating Euro Classification

20mm thick EPS panel used in V-Clad has Euro Classification of Reaction to Fire EN13501-1: 2018; Class E.

## Ordering

The V-Clad system is priced per square metre. System materials are quantified based on area including the panel, fasteners, adhesive, brick slips, and mortar. Base trim and pistol corners are priced separately.

When ordering please state the nett area of the wall and give the total linear metres of the corner length, identifying dimensions of external corners, window reveals and heads. Please also advise base trim and expansion joint requirements.

## Delivery

Materials are normally palletised. Delivery may be by pallet network or dedicated vehicle and may have self-offload equipment. Please advise of any particular site requirements or restrictions at time of ordering.

All deliveries must be thoroughly inspected prior to signing delivery note and any damage or missing items should be noted on the delivery note and notified to Eurobrick immediately.

**Material handling and storage** System materials must be safely handled and stored to prevent damage. V-Clad panels should be protected from direct sunlight and wind damage. Brick slips should be kept clean and dry. Mortar and adhesive should be stored under cover in dry conditions.

### PLEASE NOTE

Eurobrick Systems kit components must be used and fixed in accordance with these installation instructions.

# Panel installation

## CAUTION!

PPE should be worn at all times during installation.

## Placement of first panel

The first panel may be positioned anywhere along the wall, we suggest beginning at an outside corner. Align the panel in such a way as to obtain a full 65mm brick at the soffit or top edge of the wall or refer to another consistent datum such as window head height. When you have established the proper height, place the 2m level in the brick track and level the panel.

## Cutting panels

Where panels have to be cut, this must be done carefully, using a utility knife or saw.



## Panel fastening

### Fastening layout

Fasteners should be used at a rate of 15 per square metre or: 1 fastener every 4 courses vertically and 4 across the panel horizontally, starting 50mm from each edge. See Figure 3. Fasteners should be fixed every other course at building corners and openings.




Figure 3

## PLEASE NOTE

That top and bottom courses of every panel or part panel must be properly retained with a row of fasteners.

When installing stone slips or heavier brick slips, extra fasteners should be used every other course. Refer to stone fixing layout on website. Adhesive to be used at all horizontal and vertical joints to prevent the ingress of moisture.

When stacking panels one above another, be sure to align weathered joints correctly.



### Sealing joints

Adhesive or sealant should be used to seal panel abutments to prevent water penetration.



### Fixing panel

If fixing direct to masonry, drill through backer panel into substrate. Diameter and depth of hole varies with fixing type. Typically, 8-10mm diameter x 60mm penetration into substrate. Drive the masonry fixing using a hammer or mallet, full depth into the hole until the fixing faceplate is flush with backer panel surface.

If fixing to timber, using power screw driver, fix the screw and washer fully home until washer and screw head are flush with back panel.

## IMPORTANT

To achieve proper attachment the panel fasteners must penetrate the substrate. The substrate must be flat and stable and strong enough to provide firm anchorage for fixings. Where fixing to thinner sheathings, the fixings should penetrate the sheathing and the supporting member. See Figure 4.




Figure 4



### Base trim

Before fastening the bottom 8-10 courses of the panel, we recommend the installation of our base trim. The base trim will protect the bottom edge of the panel from damage caused by rodents or insect infestation. See Figure 5.

Aluminium base trim can be supplied in 2.5m lengths.

### Installation

1. Trim the lowest rib from the bottom edge of the panel.
2. Insert the base trim.
3. Use a single brick as a guide to set the trim at the proper height. From trim to topside of next rib should be 75mm.
4. Fasten the base trim and panel-together to the substrate following the instructions for panel fastening.




Figure 5

## Panel installation at corners

### Inside corner

When installing the panel at an inside corner, butt the edge of the panel up to the face of the panel on the adjoining wall and seal with adhesive. Brick slips should be cut into corners on alternate courses so as to replicate the alternate course internal corner bonding of full brickwork. See Figure 6.

If required, mastic sealant can be applied to close corner joint.

### Outside corner

When installing panels at an outside corner:

1. Panels must overlap and be sealed with adhesive or sealant to prevent the creation of a void in the area behind brick. See Figure 7.



2. Where higher windloads are anticipated, fasteners should be installed every other course at external corners.
3. Align the brick tracks of the two panels at the corner very carefully to ensure continuity of the working level around the building.




Figure 6




Figure 7

## Panel installation at doors, windows and other obstructions

When cutting panels to fit around windows, doors and other obstructions, allow a clearance of approximately 3mm between the edge of the panel and the obstruction. See Figure 8.




Figure 8




Figure 9

## Panel installation at termination

### Below ground

When pavement or road surfaces are to be installed next to Eurobrick Systems, care must be taken to prevent damage caused by movement through settling, expansion and freeze/thaw cycles. A fibrous control joint (minimum 25mm) must be placed between the building and the pavement, road or natural ground to allow independent movement. See Figure 9. A damp proof course should be extended through the system and brick slips to prevent moisture from the ground being drawn up through brick slips or behind panels. Please note, where a cavity is included, provide weepholes through the system at 1.2m centres. See Figure 10.

### Above ground

A minimum of 40mm between Eurobrick Systems termination and pavement or road is required. This is to allow for expansion/heave and prevents damage to the bottom of the cladding system. In colder climates or expansive soils, allow greater clearance as required.




Figure 10

## Panel expansion joint installation

To prevent damage resulting from the natural expansion and movement of brick, expansion joints must be constructed. The following is a general guide for expansion joint location. See expansion joint Figure 11.

1. In large walls, every 6m horizontally and vertically. The initial movement joint should be located 1200mm to 2400mm from the building corners.
2. Where walls of different heights intersect.
3. Between new and existing construction.
4. Where dissimilar exterior wall materials meet.
5. Between every other floor.

### PLEASE NOTE

Eurobrick cladding movement joints may not necessarily align with substrate expansion joints.




Figure 11

## Fire breaks

Some installations will require design and construction of fire break details to cavities and/or the system. Please note all fire breaks/defence design remains the responsibility of qualified consultant or architect.

### CAUTION!

Do not leave unbricked panels exposed to direct sunlight for more than 24 hours. Excessive exposure may have a detrimental effect on panel composition, from UV light and climate conditions.

# Brick application

## Surface preparation

Make certain that panel and brick surfaces are dust free and dry. Failure to do so will result in poor adhesion to the brick panel.

## Setting out

Start by attaching corner bricks to the most visible outside corner.

1. Apply a single 10-12mm bead of adhesive to the inside faces of corner bricks. Push them into the track profile. Once the corners are placed use a straight edge to align them as well as possible.



2. To determine brick spacing and setting out, apply 9-12mm bead of adhesive about 3/4 of the way up each course, to two courses on the panel and fix slips along two courses as far as first natural break (door/corner/expansion joint). The adhesive should cover the fastener heads. Try to space bricks with 10mm vertical joints, but so that end of run finishes with whole or half brick. Joints can be opened or closed within range of 7mm to 15mm to assist. Joints should be consistent size.




Figure 12

### BRICK MIXING

Please note brick slips can vary in length and colour shade. Slips should be mixed from various boxes/pallets to ensure even distribution of brick characteristics.

3. When the desired spacing is achieved, use a spirit level and marker pen to draw vertical plumb lines on the panels. These should be drawn every 5 or 6 bricks across the wall. Pairs of lines should be drawn to allow correct alignment in bond of alternating courses. Fix slips at plumb lines first before filling in remaining spaces. See Figure 12.
4. Where working around windows and doors the bond may be broken. Avoid using pieces less than half a brick and use additional cut pieces such as three-quarter closers to maintain reasonable bond pattern.

Another factor in brick spacing is whether or not there are obstructions in the wall.

### Without obstructions

If the wall has no obstructions lay two courses of brick working to the next inside or outside corner or expansion joint. Space the brick to allow a full brick at the corner. Ensure joints are consistent size.

When you have achieved the desired spacing, draw plumb lines on the panels as described previously. The plumb line serves as a reference for every other course. For courses with no plumb line, be sure to centre the brick on the vertical joint of the course above and below.



### With obstructions – doors, windows and other obstructions

Adjust the brick spacing to prevent the need for a mortar joint or very small piece of brick at the edge of the window, door or obstruction. Try to avoid using pieces smaller than a half brick adjacent to doors and windows or finishing a course with a mortar joint. Maintain consistent perp joint size and ensure brick spacing/coursing is consistent each side of the obstruction.

Once the desired spacing has been achieved, section the wall as described previously.

### CAUTION!

Once backer panels have been installed they should be bricked immediately. Where this is not possible, panels should be protected from exposure to direct sunlight which can cause deterioration of material due to UV light.

### Brick layout exception

There are times when it is not possible to run a course of brick to determine proper layout and spacing. In these cases determine the layout mathematically.

The length of a brick is 215mm and the standard mortar joint is 10mm; use 225mm as the standard increment.

## Brick slips installation

### Standard

After plumb lines have been drawn, apply a 9mm - 12mm bead of adhesive 3/4 of the way up the course. Continue adhesive application for approximately 20 courses.

After applying adhesive, push bricks into brick tracks. Repeat the procedure for each successive section.

### Soldier course

Installing brick slips in vertical soldier courses uses 3 'brick tracks' on the backer panel. To prepare the panel:

1. Using a craft knife, carefully slice behind the rib to remove the 2 ribs 'obstructing' the soldier course.



2. Apply adhesive to the upper and lower edges of the soldier course, or to the back of the slips if preferred.
3. Attach slips in soldier formation taking care to achieve appropriate bond.



4. A temporary piece of batten may be required to hold bricks in place while adhesive cures. This can be screw fixed to substrate through the brick joints.

### Window and door openings

#### Flush

When applying brick around window or door openings which have linings, trims or frame with front faces that are slightly set forward from the front face of the brick slips, place the factory formed edge of the brick slip (not a cut edge) against the lining, trim or frame to provide the best finish. See Figure 13.




Figure 13

#### Recessed

When working around recessed window and door openings, install the backer panel allowing a 3mm wide expansion gap back from the edge or external corner to the opening reveal. In many cases, the backer panel will not be installed over the reveal to the opening because the thickness of the brick slip and backer panel combined may be too wide for the width of the window or door frame creating an obstruction.

The detail for installing brick slips in the reveal will vary depending on the depth of the reveal and the thickness of the wall construction.

#### CAUTION!

Do not attach brick directly to any wood surface.



**Masonry:** Brick may be attached directly to the masonry surface. To install brick, apply a bead of adhesive under the top edge of the brick track on the panel and onto the surface of the reveal. Push corner brick into the brick track. See Figure 14.

**Timber:** To install cladding over timber, the timber surface must be covered with a waterproof membrane. Apply the brick slips as outlined under MASONRY. Where panel cannot be used on the reveals to an opening, the timber surface should be covered with a waterproof membrane and a fine gauge wire mesh or expanded metal lath nailed in place as a key for the brick slip adhesive and mortar.

#### PLEASE NOTE

If the length of the return exceeds 102mm, a combination of corners and straight slips must be used. Where Eurobrick Systems panels are not installed over the window/door reveal area and the brick straights can not be pushed into the brick tracks, we recommend that the slips are held in place using nails tapped into the wall surface at the bottom edge of the brick. Remove nails when you are certain that the brick slips are firmly attached. See Figure 15.




Figure 14




Figure 15

#### Cills

Be sure that window cills extend beyond the brick edge. See Figure 16.




Figure 16

## Pointing

Europoint instructions are available to download at [eurobrick.co.uk/brochures](http://eurobrick.co.uk/brochures) or call 0117 971 7117 for a printed copy. A Europoint video is also available to view on our YouTube channel.

### Mortar

Eurobrick Systems Europoint mortar is specially formulated and packaged in easy to use 25kg bags.

### Mixing mortar

Mortar is easily mixed in a 25 litre bucket, using an electric drill with a “paddle” mixer attachment. The consistency should be slightly wetter than standard mortar. We recommend about 4–4.5 litres of water per 25kg bag. A final test of proper consistency is the flow of the mortar from the grout bag; it should flow slowly from the tip.

#### CAUTION!

Mortar should be mixed outside or in well ventilated areas. Appropriate PPE should be used.

### Filling the pointing bag

Roll back the top edge of the pointing bag once to create as large an opening as possible. With a scoop, fill the bag 2/3 full being careful not to get any mortar on the top edge of the bag. After filling the bag hold it just above the fill point with one hand and twist with the other until the opening is closed tightly.

### Point the joints

Pointing mortar should not be applied in temperatures below 4°C.

### To apply mortar

1. Squeeze the bag with a slight twisting motion at the end to keep the bag firm at the tip.
2. Whether to fill the horizontal (bed) joints or vertical (perp) joints first is personal preference.
3. Joints should be filled almost to the point of overflow. Ensure joints are properly filled with no voids or gaps.
4. For a consistent finish, pointing of whole elevations should be completed on the same day, if possible.

#### IMPORTANT

Only point as large an area as can be tooled before the mortar becomes too stiff.



Applying mortar



Tooling

### Tooling the joints

Allow mortar to set until firm. It should have a dull finish, be moist but not wet and somewhat gritty. The mortar joint should be tooled to a “bucket handle finish” using a standard pointing tool. Where thicker slips (20mm +) are being pointed, recessed or weather struck mortar joint finish can be achieved using appropriate tools.

With a joint tool or 18mm piece of pipe begin striking or tooling the bed joints first, and then the vertical joints. All mortar joints must be tightly sealed to the brick edge.

When tooling you may discover holes or voids in the mortar. Fill the holes with the mortar droppings and retool.

#### CAUTION!

Do not tool the joint too soon or too deep. Tooling early will create a creamy surface on the mortar.

### Brushing

After the joints have been tooled, the area must be brushed with a soft bristle brush.

Allow the area to dry for 10–15 minutes or until the excess mortar on the brick edges has dried. Brushing too soon will create permanent brush marks in the mortar.

Brushing should be done at a 45 degree angle to ensure that the mortar is not pulled away from the brick edges.



#### CAUTION!

Newly pointed brickwork should be protected from frost or inclement weather with hessian or similar covering.



## Cleaning

After job completion, it may be necessary to clean the brick. The initial clean should not take place sooner than 48 hours after pointing, using clean water and a hard bristle household brush. If further cleaning is required, use a proprietary brand masonry cleaner. Refer to the manufacturers mixing instructions and precautionary steps before cleaning wall.

### IMPORTANT

Do not begin cleaning until mortar has properly cured. Allow a minimum of 48 hours.

## Sealing

To ensure weather tightness, all joints and abutments should be properly sealed as illustrated in Figure 17 and throughout the installation guide.





Figure 17



## Accessories

All necessary accessories are available from stock. Please see our Accessories Leaflet for more details. Please call +44 (0)117 971 7117 with any queries you may have.



## Visit our showroom

**You can see all of our cladding systems and finishes at our showroom which is open to visitors Monday-Friday (excluding bank holidays) 9am - 4.30pm. An appointment is not necessary but if you would prefer to make one you can do so by calling us on 0117 971 7117.**

### Please note

Our brick slips are kiln fired natural clay products and while every effort is made to ensure consistency, variations in size, colour shade and texture can occur. This should not be viewed as a fault in production and should be taken into account at the design stage of the project.

Mortar colour variations can be expected due to the porosity of the brick, finishing techniques, mixing procedures and weather conditions (temperature, humidity and wind) at time of application.



# EUROBRICK®

Eurobrick Systems Ltd  
Unit 5, Newbridge Trading Estate,  
Newbridge Close, Bristol, BS4 4AX

T: +44 (0)117 971 7117  
info@eurobrick.co.uk www.eurobrick.co.uk

As part of its continuing product development and improvement policy, Eurobrick Systems Ltd reserve the right to change product specifications without prior notice.

Terms and conditions apply, please see our website for more details.

© 2025 Eurobrick Systems Limited. All rights reserved.

